QUICK START GUIDE TIMEBAR



3.5 mm Jack Timecode In/Out

POWER Button On/Off/Mode

USB-C Port Charging & Firmware Update

POWER ON

Short press POWER:
Timebar starts up waiting to be synchronized by app or external timecode

Long press POWER:
Timebar starts up generating timecode with Time of Day (RTC)

POWER OFF

Long press POWER:
Timebar turns off

MODE

Press POWER: Enter Mode Selection
Press A or B: Browse Modes
Press POWER: Select Mode

TIMECODE

A: Show User Bits for 5 Seconds
B: Hold Timecode for 5 Seconds

TIMER

A: Select one of 3 Timer Presets
B: Start/Stop

STOPWATCH

A: Reset Stopwatch
B: Start/Stop

MESSAGE

A: Select one of 3 Message Presets
B: Start/Stop

SLATE

A: N/A
B: N/A



BRIGHTNESS

Press A & B at once:
Enter Brightness Selection

Press A or B:
Select Brightness Level from 1 to 31
A = Auto Brightness

BRIGHTNESS BOOST

Press A & B twice:
Brightness Boost for 30 Seconds

FRAME RATE

All SMPTE 12-M Standard frame rates. While in Timecode Mode the selected frame rate flashes on first frame



BLUETOOTH

Appears when Timebar has a connection to a mobile device and is operated via Setup App

BATTERY

Appears while in Mode Selection and indicates remaining battery capacity.
Flashing indicates battery is nearly empty.