


QUICK START GUIDE TIMEBAR



POWER ON

Short press POWER:

Timebar starts up waiting to be synchronized by app or external timecode

Long press POWER:

Timebar starts up generating timecode with Time of Day (RTC)

POWER OFF

Long press POWER:

Timebar turns off

MODE

Press POWER: Enter Mode Selection

Press A or B: Browse Modes

Press POWER: Select Mode

TIMECODE

A: Show User Bits for 5 Seconds

B: Hold Timecode for 5 Seconds

TIMER

A: Select one of 3 Timer Presets

B: Start/Stop

STOPWATCH


A: Reset Stopwatch

B: Start/Stop

MESSAGE

A: Select one of 3 Message Presets

B: Start/Stop



BRIGHTNESS

Press A & B at once:

Enter Brightness Selection

Press A or B:

Select Brightness Level 1-31

A = Auto Brightness


BRIGHTNESS BOOST

Press A & B twice:

Brightness Boost for 30 Seconds

FRAME RATE

All SMPTE 12-M Standard frame rates. While in Timecode Mode the selected frame rate flashes on first frame



BLUETOOTH

Appears when Timebar has a connection to a mobile device and is operated via Setup App

BATTERY

Appears while in Mode Selection and indicates remaining battery capacity.

Flashing indicates battery is nearly empty.